




TRAEGER[®]
WOOD FIRED GRILLS







TIMBERLINE

ASSEMBLY GUIDE



IMPORTANT: RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

TRAEGER PELLET GRILLS LLC
1215 E. WILMINGTON AVE., SUITE 200
SALT LAKE CITY, UT 84106









A good friend
and a six pack
of your favorite
beverage should
get the job done!



PLEASE READ THIS ASSEMBLY GUIDE AND YOUR OWNER'S MANUAL BEFORE INSTALLATION AND USE OF YOUR TRAEGER® GRILL. FAILURE TO FOLLOW THE INSTRUCTIONS IN THIS ASSEMBLY GUIDE AND YOUR OWNER'S MANUAL COULD RESULT IN PROPERTY DAMAGE, BODILY INJURY, OR EVEN DEATH.









Scan this code for digital/video instructions.












Scan this code for digital/video instructions.












Scan this code for digital/video instructions.






Scan this code for digital/video instructions.







Scan this code for digital/video instructions.



25




26




27

OPTION A




27


OPTION B



28





29






Scan this code for digital/video instructions.




Scan this code for instructions on built-in assembly.


QUICK START GUIDE




Press the main power button located on the front of the grill to ON.



Press any button to turn on the control.



Turn the selection dial right or left to select the temperature. Press dial, then press and hold the on-screen prompt.



To shut down the grill, press and hold the selection dial for 3 seconds.